

Features:

- Storage compartment for the inflation needle located inside the T-bar handle
- Durable all-plastic hand pump for inflating small to medium size inflatables
- Manual design for easy operation
- Compact design for easy storage and transport

Included Parts:

- Ⓐ One manual air inflation pump
- Ⓑ One inflation needle



Instructions:



Locate the end cap of the storage area on the handle.



Flip open the cap on the end of the handle.



Add or remove the needle into or out of the storage area and close the cap.



Attach or detach the inflation needle by screwing or unscrewing it to the opposite end of the hand pump.



Locate the valve opening, lightly moisten the inflation needle and gently insert it straight into the valve. Pump the handle up and down to inflate the object to the required pressure.



Close the end cap when not in use.