hamp



Features:

- Easy fold 1.5" welded steel frame
- Heavy-duty polyethylene net with Velcro[®] corner loops
- Fold hinges with simple locking pin system
- 72" x 36" x 36"

Instructions:

- The Champion Sports Easy Fold Soccer Goal is designed to be easy to set up and transport.
- 1. Pole sections are numbered for easy identification. If not already installed, insert eight pushbuttons into the narrow ends of eight pole sections. Figure 1


PARTS: • 8 Poles

• 1 Net

• 4 Stakes

• 26 Velcro[®] Loops

- 2. Assemble top pole sections 1, 2 & by lining up the pushbuttons in pole 2 with corresponding holes in pole sections 1. Repeat the process for lower pole sections 1, 2 & 1. Figure 1
 - **NOTE:** The top pole section assembly 1-2-1 has the warning label facing toward the front of the goal.
- 3. Unfold pole sections 3 & 5 and lock at a 90° angle using a locking pin. Repeat this step for pole sections 4 & 5. These pole sections are pre-assembled.
- 4. Attach assembled top pole sections 1-2-1 to pole sections 5 by lining up the pushbuttons with the corresponding holes. Then attach assembled bottom pole sections 1-2-1 to pole sections 3 & 4 in the same manner. This will complete the frame assembly. Figure 1
- 5. Lay the net out to locate the corners A & B. (THE NET DIAGRAM IS FOR ILLUSTRATION PURPOSES ONLY, THE ACTUAL NET DIMENSIONS MAY VARY). Figure 2
- 6. Attach the net to the frame starting at corners A & B. Wrap a self-stick fastener around the frame and through the net at each corner.
- 7. Continue to attach self-stick fasteners evenly spaced around the frame. Use 5 fasteners on the top section and the rear base section, use 4 on each vertical side section and 4 on each side base section. Position "J" hooks in for securing the goal to the ground. Figure 3



Champion Sports ● One Champion Way ● Marlboro, NJ ● 07746-0368 ● 888-980-1200