

Rebounder Wall Main Frame x 1



Pole #1 x 2



Pole #3 x 2




Pole #2 x 1




Pole #4 x 1




Pole #5 & Pole #6



Long Screw x 2



Middle Screw x 1



Short Screw x 1



x 1




x 1

Assembly Instructions:

1. Lay out the pieces.
2. With a hand on the top and bottom of the frame, apply pressure to unfold rebounder wall. Lock the hinge plate on both sides using the 2 longest screws.
3. Connect both short "L" shaped #1 poles to pole #2 to create a "U" shape.
4. Insert the short front legs into the front pegs on the main frame.
5. Connect both long "L" shaped #3 poles to pole #4 to create a second "U" shape.
6. Flip the frame over and insert the long back legs into the back pegs on the main frame.
7. Attach pole #5 to pole #4 using the provided middle screw, then loosen the knob handle on pole #5.
8. Lift the back legs so that pole #6 can be attached to the back of the main frame, using the shortest screw.
9. Lock the knob handle on pole #5, and stand up the rebounder.
10. To adjust the angle of the rebounder, unlock the knob handle on pole #5, move the rebounder into position, and lock the knob handle again.

Knob handle



⚠ WARNING



- Assembly and adjustments should only be completed by adults.
- Metal may have sharp edges.
- Never climb on the rebounder wall.

